

DGPS - INSTALLATION INSTRUCTIONS

Supplemental – for VI

Connecting the three wires

Wire Color	Connect to	Description
Black	GND	(Ground)
Black(Marked)	IGN	(+12v Ignition Switch)
Clear	VSS	(Vehicle Speed Signal)

The **Vehicle Speed Signal (VSS)** line is a wire which runs from the *engine's rotation sensor* to the back of the dashboard, and connected to the speedometer.

- Identify the **VSS** line by connecting a voltmeter to it and to GND, see that the line is toggling (between 0v and a positive voltage) as you move the car some 20 Ft. (slowly forward or backward).
- Connect the clear wire to the **VSS** line.



264 Medea Way Central Islip, NY 11722 Tel.: (516) 236-8465